


Atlas Zenith (Type 9) Frame



Atlas Zenith (Type 9) Frame

Item	Part No.	Description
1	Z-1401	Handle Frame
2	Z-1401A	Handle Assembly
	Z-1401A-AM	Handle Assembly, After Market
3	Z-1402	Pull Rod
4	Z-1403	Support Base
5	Z-1404	Screw
6	Z-1405	Ball
7	Z-1406	Spring
8	Z-1407	Pin
9	Z-1408	Screw
10	Z-1409	Chain (includes items 10-13)
11	Z-1410	Pin
12	Z-1411	Adjusting Screw
13	Z-1412	Nut
14	Z-1413	Washer
15	Z-1414	Lock Washer
16	Z-1201	Screw
17	Z-1202	Washer
18	Z-1203	Retainer
19	Z-1204	Oiler
20	Z-1205	Roll Pin
21	Z-1206	Bell Crank
22	Z-1207	Shoulder Bolt

Item	Part No.	Description
23	Z-1208	Rod Pin
24	Z-1209	Clevis
25	Z-1210	Snap Ring
26	Z-1211	Lift Link Axle
27	Z-1212	Push Rod
28	Z-1213	Push Rod Hex Nut
29	Z-1215	Roll Pin
30	Z-1216	Push Rod Pin
31	Z-1217	Load Wheel Axle
32	Z-1218	Roll Pin
33	Z-1219	Pivot Axle
34	Z-1220	Load Wheel Bracket
35	Z-1221	Roll Pin
36	Z-1222	Frame
37	Z-1223	Snap Ring
38	Z-1224	Spacer
39	Z-1225	Dust Cover
40	Z-1226	Bearing
41	Z-1227	Load Roller Assembly, Black Ultra-Poly On Steel Hub W/ Bearings
	GWK-ATZ-LW	Load Wheel Kit, (2) Black Ultra-Poly Load Roller Assemblies (70D), W/ Bearings, Axles & Fasteners
42	Z-1228	Lock Washer

Load Wheel Kit

